



# CONFIGURATION AND KIT LIST

## K1



**K1-KS28**  
**(LA12X)**



# CONFIGURATION AND KIT LIST

## K1

### K1 KIT LIST - NOMINAL FULL PACKAGE

K STANDARD

| K1 SYSTEM           | DESCRIPTION   | 48 K1 - 24 K2 |
|---------------------|---|---------------|
| K1                  | 3-way full-range active WST® enclosure New polyurethane based coating           | 48            |
| K1-PLA              | Removable front dolly for K1 or K1-SB enclosure                                 | 0             |
| K1-COV              | Protective cover for K1 enclosure   | 0             |
| K1-CHARIOT2         | Chariot for 4 K1 or 4 K1-SB   | 12            |
| K1-CHARIOTCOV       | Protective cover for 4 K1/K1-SB on CHARIOT                                      | 12            |
| DO.7                | Speaker cable: 8 x 4mm <sup>2</sup> CA-COM 0.7m length                          | 24            |
| DO25                | Speaker cable: 8 x 4mm <sup>2</sup> CA-COM 25m length                           | 24            |
| K1-BUMP             | Structure for flying & stacking K1 and K1-SB arrays                             | 4             |
| K1-DELTA            | Rigging accessory for rear attachment of 2 motors to K1-BUMP                    | 4             |
| K1-LASERMOUNT       | K1 Laser mount  | 4             |
| K-BUMPFLIGHT        | Modular flight case for 2 K1-BUMP or 2 K2-BUMP                                  | 2             |
| LA-RAK II           | Touring Rack (complete with 3 x LA12X amplified controllers)                    | 10            |
| LA-RAK BUMP         | Structure for flying 4 LA-RAK   | 3             |
| DOM2                | 6 pair multiconductor cable AMP LINK 2m length                                  | 10            |
| DOM45               | 6 pair multiconductor cable CROSS LINK 45m length                               | 5             |
| DOMF                | Multipair cable adapter LINK-BREAKOUT 6 LR3 female                              | 5             |
| DOMM                | Multipair cable adapter LINK-BREAKOUT 6 LR3 male                                | 2             |
| DOMP-2              | Male/Male adapter LINK-EXTEND for AMP & CROSS LINK                              | 2             |
| KARA                | 2-way modular WST® enclosure  | 12            |
| SP.7                | Speaker cable: 4 x 4mm <sup>2</sup> NL4 0.7m length                             | 8             |
| DO25                | Speaker cable: 8 x 4mm <sup>2</sup> CA-COM 25m length                           | 4             |
| DOFILL-LA8          | Speaker cable extension for active 2 way enclosures CA-COM > 2 NL-4 length 3.5m | 4             |
| KARA-DOWNK1         | Flying bumper for rigging KARA under K1 or K1SB                                 | 4             |
| <b>K1-SB SYSTEM</b> |   |               |
| K1-SB               | K1 System subwoofer 2 x 15"   | 24            |
| K1-PLA              | Removable front dolly for K1 or K1-SB enclosure                                 | 0             |
| K1-SBCOV            | Protective cover for K1-SB enclosure  | 0             |
| K1-CHARIOT2         | Chariot for 4 K1 or 4 K1-SB   | 6             |
| K1-CHARIOTCOV       | Protective cover for 4 K1/K1-SB on CHARIOT                                      | 6             |
| DO25                | Speaker cable: 8 x 4mm <sup>2</sup> CA-COM 25m length                           | 8             |
| DOSUB-LA8           | Speaker cable breakout for passive enclosures CA-COM > 4 NL-2 length 5m         | 8             |
| K1-BUMP             | Structure for flying & stacking K1 and K1-SB arrays                             | 4             |
| K1-DELTA            | Rigging accessory for rear attachment of 2 motors to K1-BUMP                    | 4             |
| K-BUMPFLIGHT        | Modular flight case for 2 K1-BUMP or 2 K2-BUMP                                  | 2             |
| LA-RAK II           | Touring Rack (complete with 3 x LA12X amplified controllers)                    | 2             |
| LA-RAK BUMP         | Structure for flying 4 LA-RAK   | 1             |
| DOM2                | 6 pair multiconductor cable AMP LINK 2m length                                  | 2             |
| DOM45               | 6 pair multiconductor cable CROSS LINK 45m length                               | 1             |
| DOMF                | Multipair cable adapter LINK-BREAKOUT 6 LR3 female                              | 1             |



# CONFIGURATION AND KIT LIST

## K1

### K2 SYSTEM

|               |  |    |
|---------------|--|----|
| K2            | 3-way full-range active WST enclosure                                      | 24 |
| K2-CHARIOT    | Chariot for 4 K2   | 6  |
| K2-CHARIOTCOV | Protective cover for 4 K2 on CHARIOT                                       | 6  |
| K2-JACK       | 4 tilt adjustment screw jacks + bar for K2-CHARIOT                         | 6  |
| DO.7          | Speaker cable: 8 x 4mm <sup>2</sup> CA-COM 0.7m length                     | 12 |
| DO25          | Speaker cable: 8 x 4mm <sup>2</sup> CA-COM 25m length                      | 12 |
| K2-BUMP       | Structure for flying K2 arrays (incl. 1 extension sling + 1 laser adapter) | 4  |
| K2-BAR        | Extension bar for K2-BUMP  | 4  |
| K1-DELTA      | Rigging accessory for rear attachment of 2 motors to K1-BUMP               | 4  |
| K2-LASERMOUNT | K2 Lasermount (compatible TEQSAS-SSE ProSight-Align Array)                 | 4  |
| K2-RAKMOUNT   | 4 mounting cradle for LA-RAK (incl. rack stabilizer)                       | 4  |
| K-BUMPFLIGHT  | Modular flight case for 2 K1-BUMP or 2 K2-BUMP                             | 2  |
| K2-LINK       | Rigging accessory for rear attachment of K2 below K1                       | 4  |
| LA-RAK II     | Touring Rack (complete with 3 x LA12X amplified controllers)               | 4  |
| LA-RAK BUMP   | Structure for flying 4 LA-RAK  | 4  |
| DOM2          | 6 pair multiconductor cable AMP LINK 2m length                             | 4  |
| DOM45         | 6 pair multiconductor cable CROSS LINK 45m length                          | 2  |
| DOMF          | Multipair cable adapter LINK-BREAKOUT 6 LR3 female                         | 2  |
| DOMM          | Multipair cable adapter LINK-BREAKOUT 6 LR3 male                           | 1  |
| DOMP-2        | Male/Male adapter LINK-EXTEND for AMP & CROSS LINK                         | 1  |

### KS28 SYSTEM

|           |   |    |
|-----------|---|----|
| KS28      | Flyable subwoofer 2 x 18"   | 24 |
| KS28-PLA  | Removable front dolly on wheels for 1 x KS28                            | 24 |
| KS28-COV  | Protective cover for 1 x KS28   | 24 |
| DO25      | Speaker cable: 8 x 4mm <sup>2</sup> CA-COM 25m length                   | 6  |
| DOSUB-LA8 | Speaker cable breakout for passive enclosures CA-COM > 4 NL-2 length 5m | 6  |
| LA-RAK II | Touring Rack (complete with 3 x LA12X amplified controllers)            | 2  |
| DOM2      | 6 pair multiconductor cable AMP LINK 2m length                          | 2  |
| DOM45     | 6 pair multiconductor cable CROSS LINK 45m length                       | 1  |
| DOMF      | Multipair cable adapter LINK-BREAKOUT 6 LR3 female                      | 1  |
| DOMM      | Multipair cable adapter LINK-BREAKOUT 6 LR3 male                        | 1  |

### TECH TOOLCASE

|                |                             |   |
|----------------|-----------------------------|---|
| TECH TOOL CASE | System technician tool case | 1 |
|----------------|-----------------------------|---|

### TRAINING

|          |  |   |
|----------|--|---|
| TRA-DOM  | On-site training 1 day (domestic)        | 0 |
| TRA-REG  | On-site training 1 day (regional)        | 0 |
| TRA-INT  | On-site training 2 days (international)  | 1 |
| TRA-ADD  | Additional on-site training day          | 1 |
| TRA-VOU1 | 1 day training valid for one participant | 0 |



# CONFIGURATION AND KIT LIST

## K1

---

### SERVICE STARTER KIT K1

|            |                                   |   |
|------------|-----------------------------------|---|
| KR HSBC33  | Kit diaphragm for 3" driver       | 3 |
| KR HPBC33  | Kit HP BC33 Driver 3" - 20 ohms   | 3 |
| KR HPPH62  | Kit HP PH62 Speaker 6.5" - 8 ohms | 4 |
| KR HPPH154 | Kit HP PH154 Speaker 15" - 8 ohms | 2 |
| KR PIN163  | Kit K1 6 ball head pins           | 1 |
| KR PIN183  | Kit K1 bumper 2 pins              | 1 |

---

### SERVICE STARTER KIT K1-SB

|            |                                   |   |
|------------|-----------------------------------|---|
| KR HPPH154 | Kit HP PH154 Speaker 15" - 8 ohms | 2 |
| KR PIN163  | Kit K1 6 ball head pins           | 1 |

---

### SERVICE STARTER KIT K2

|            |   |   |
|------------|---|---|
| KR HSBC34  | KitDiaphragm for HP BC34II (3" driver - 8 ohms) | 2 |
| KR HPBC34  | Kit HP BC34 Driver 3" - 8 ohms                  | 2 |
| KR HPFA61  | Kit HP FA61 Driver 6.5" - 8 ohms                | 2 |
| KR HPBC125 | Kit 12" speaker - 8 ohms                        | 2 |
| KR PIN163  | Kit K1 6 ball head pins                         | 2 |
| KR PIN1394 | Kit 2 x pin 1394                                | 2 |
| KR PIN1542 | Kit 2 x pin 1542                                | 1 |

---

### SERVICE STARTER KIT KARA

|           |   |   |
|-----------|---|---|
| KR HSBC34 | KitDiaphragm for HP BC34II (3" driver - 8 ohms) | 1 |
| KR HPBC34 | Kit HP BC34 Driver 3" - 8 ohms                  | 1 |
| KR HPPH85 | Kit HP PH85 Speaker 8" - 16 ohms                | 2 |
| KR PIN621 | Kit 10 pins short round head screws & rivets    | 1 |
| KR PIN601 | Kit 10 pins long T-shaped head screws & rivets  | 1 |

---

### SERVICE STARTER KIT KS28

|        |                |   |
|--------|----------------|---|
| G03229 | KR 18" speaker | 2 |
|--------|----------------|---|

### NOMINAL PACKAGE SPLIT 1/2 1/2

